

用户指南

便携式冲洗器

记录您的型号：

Record your model number: _____

English, page 12

KOHLER®

1521675-T5-B

Thank You for Choosing KOHLER

需要帮助？ 请联系我们的客户服务中心。

- 中国大陆：+(86) 800-820-2628, +(86) 400-820-2628
- 中国香港、中国澳门、中国台湾：+(852) 3125-7728
- 保养和清洁：kohler.com.cn/support/care-and-cleaning

质保

本产品支持**科勒®厨卫产品三年有限质保**，详见包装所附的《合格证》。

重要信息



小心：人身伤害或产品损坏风险。请勿将喷嘴插入到身体中。



小心：存在产品损坏的风险。若将长时间不使用本设备，请拆下电池。



小心：存在产品损坏的风险。请勿使用洗涤剂或坐便器清洁剂清洗水瓶组件。



小心：存在产品损坏的风险。请勿将锂离子电池与本产品一起使用。将锂离子电池暴露在水中可能会导致火灾。

请仅使用可饮用的冷水。

请定期清洗水瓶组件的内部，以防止细菌生长。


不满 10 岁的儿童在使用本产品时需要监护。

保存说明书


建议使用的矿泉水瓶

地区	品牌		标记
	名称	容积	
中国	百岁山	348 ml/570 ml	转接头
	农夫山泉®	380 ml/550 ml	
	怡宝®	350 ml/555 ml	

零件识别





安装电池



 **小心：** 存在产品损坏的风险。请勿将锂离子电池与本产品一起使用。将锂离子电池暴露在水中可能会导致火灾。


- ☐ 从水瓶组件上松开螺钉并拆下便携式清洁剂。
- ☐ 逆时针旋转电池盖，将其拆下。
- ☐ 安装随附的两节 AAA 电池，并重新安装电池盖。

装配便携式清洁器




- ☐ 将饮用水灌装到水瓶组件中的注水线位置。
- ☐ 将便携式清洁器上的线与水瓶组件上的线对齐。然后拧紧。

安装矿泉水瓶



- ☐ 将接头安装在便携式清洁器的底部。
- ☐ 将矿泉水瓶插入到接头的末端。

操作



- **高：** 按下具有两个点的按钮可打开高压模式设置。再次按下该按钮可关闭。
- **低：** 按下具有一个点的按钮可打开低压模式设置。再次按下该按钮可关闭。

更换喷嘴



注： 视用户的喜好而定，可以从任意一侧安装喷嘴。

- ☐ **拆下：** 向上拉动可拆下旧喷嘴。
- ☐ **安装：** 向下按压可安装新喷嘴。

保养和清洁



小心： 存在产品损坏的风险。请勿使用专为清洁坐便器而设计的洗涤剂冲洗本产品，以避免产品损坏。

注： 请定期清洁喷嘴套件，以清除可能限制坐浴盆水流的杂质。

注： 请定期清洁水瓶内部，以清除杂质并避免水藻生长。

- 请用软毛刷清洁进水口和喷嘴套件上的滤网，以清除杂质。
- 请彻底冲洗并擦掉水瓶上的杂质。
- 使用蘸湿的软布或者海绵。切勿使用刷子或百洁布等粗糙材料来清洁外表面。
- 请使用软布蘸湿经稀释的中性清洁剂将外表面擦拭干净，以尽量抑制水藻的生长。
- 不要让清洁剂浸泡。
- 请遵循清洁剂制造商的说明进行适当应用。
- 在喷涂到整个表面之前，务必在不显眼的区域对清洁液进行测试。

Homeowners Guide

Portable Bidet

Thank You for Choosing KOHLER

Need help? Contact our Customer Care Center.

- Mainland China: +(86) 800-820-2628, +(86) 400-820-2628
- Hong Kong (China), Macau (China), Taiwan (China): +(852) 3125-7728
- **Care and cleaning:** <https://www.kohler.com.cn/support/care-and-cleaning/>

Warranty

This product is covered under the **Three-Year Limited Warranty for KOHLER® Plumbing Products**, found in the packed Compliance Certification.

Important Information



CAUTION: Risk of personal injury or product damage. Do not insert the nozzle into the body.



CAUTION: Risk of product damage. Remove the batteries if the unit will not be used for a prolonged period of time.



CAUTION: Risk of product damage. Do not wash the bottle component with detergent or toilet cleaner.



CAUTION: Risk of product damage. Do not use lithium ion batteries with this product. Exposing lithium ion batteries to water can result in a fire.

Use only cold, drinking-quality water.


Wash the inside of the bottle component periodically to prevent bacterial growth.

Children under 10 years of age require supervision while using this product.


SAVE THESE INSTRUCTIONS

Recommended Mineral Water Bottles

Region	Brand		Mark
	Name	Volume	
China	Ganten	348 ml / 570 ml	Adapter
	Nongfu Spring®	380 ml / 550 ml	
	C'estbon®	350 ml / 555 ml	





Install the Batteries



CAUTION: Risk of product damage. Do not use lithium ion batteries with this product. Exposing lithium ion batteries to water can result in a fire.


- ☐ Unthread and remove the portable cleaner from the bottle component.
- ☐ Turn the battery cover counterclockwise to remove.
- ☐ Install the two provided AAA batteries and reinstall the cover.

Assemble the Portable Cleaner




- ☐ Fill the bottle component with drinking-quality water to the water fill line.
- ☐ Align the line on the portable cleaner with the line on the bottle component. Twist to secure.

Install the Mineral Water Bottle (Optional)



- ☐ Install the adapter onto the bottom of the portable cleaner.
- ☐ Insert a mineral water bottle into the end of the adapter.



- ☐ **High:** Press the button with the two dots to turn ON the high setting. Press the button again to turn OFF.
- ☐ **Low:** Press the button with the single dot to turn ON the low setting. Press the button again to turn OFF.

Changing the Nozzle



NOTE: The nozzle can be installed from either side, depending on the user's preference.

- ☐ **Remove:** Pull up to remove the old nozzle.
- ☐ **Install:** Press down to install the new nozzle.

Care and Cleaning



CAUTION: Risk of product damage. Do not rinse this product with detergent designed for cleaning toilets to avoid product damage.

NOTE: Periodically clean the nozzle kit to remove debris that can limit water flow from the bidet.

NOTE: Periodically clean the bottle from the inside to remove debris and to avoid algae growth.

- Clean the filter screen at the water inlet and nozzle kit with a soft-bristled brush to dislodge debris.
- Thoroughly rinse and wipe away the dislodged debris from the bottle.
- Use a soft, dampened sponge or cloth. Never use an abrasive material such as a brush or scouring pad to clean external surfaces.
- Wipe the external surfaces clean with a soft cloth dampened by diluted neutral cleaner to minimize algae growth.
- Do not allow cleaner to soak.
- Follow the cleaner manufacturer's instructions for proper application.
- Always test your cleaning solution on an inconspicuous area before applying to the entire surface.

kohler.com.cn

THE BOLD LOOK
OF **KOHLER**®

©2023 Kohler Co.



1521675-T5

1521675-T5-B