


EX41445T-PTDN/PTTG/PTBG	EX41445T-SKDN/SKTG/SKBG	双把墙出脸盆龙头把手
EX41445T-CRDN/CRTG/CRBG	EX41445T-CNDN/CNTG/CNBG	双把墙出脸盆龙头把手
EX41445T-TEDN/TETG/TEBG	EX41445T-RNDN/RNTG/RNBG	双把墙出脸盆龙头把手



**订购时请说明颜色编号
**Color code must be specified when ordering

EX41445T-PTDN/PTTG/PTBG	EX41445T-SKDN/SKTG/SKBG	双把墙出脸盆龙头把手
EX41445T-CRDN/CRTG/CRBG	EX41445T-CNDN/CNTG/CNBG	双把墙出脸盆龙头把手
EX41445T-TEDN/TETG/TEBG	EX41445T-RNDN/RNTG/RNBG	双把墙出脸盆龙头把手

安装之前

BEFORE YOU BEGIN

所有的资料是按最新出版的产品资料编写而成。科勒公司保留任何时候不经通知即可改变产品特性、包装或产品可供类型的权利。

All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.

说明书包括重要的安装、保养及清洁方面的内容，请把这些资料交给用户阅读。

Please leave these instructions for the consumer. They contain important information.

注意事项：

- 1.一定要先彻底冲洗供水管以清除管道中的杂质。
- 2.检查供水管有无损坏。如需要，进行替换。
- 3.遵守当地管路安装条例。
- 4.对于EX41445T-PT**/SK**/CR**/CN**/RN**，需与双把墙出水脸盆龙头阀芯34667T-NA搭配使用。
- 5.对于EX41445T-TE**，需与双把墙出水脸盆龙头阀芯31141T-NA搭配使用。
- 6.确保在把手安装之前，双把墙出水脸盆龙头阀芯34667T-NA或31141T-NA已安装完毕。
- 7.使用时请轻拿轻放，避免陶瓷把手受到撞击、挤压摔落等外力冲击。
- 8.禁止用陶瓷把手悬挂重物、或进行超出产品设计用途的操作。
- 9.若发现陶瓷把手出现轻微裂纹，联系客服进行维修。

NOTES:

1. Flush the water supply pipes thoroughly to remove debris.
2. Inspect the supply tubing for damage. Replace as necessary.
3. Observe local plumbing codes.
4. For EX41445T-PT**/SK**/CR**/CN**/RN**, match with wall-mount dual handle lavatory faucet valve 34667T-NA.
5. For EX41445T-TE**, match with wall-mount dual handle lavatory faucet valve 31141T-NA.
6. Install the valve 34667T-NA or 31141T-NA before installing these handles.
7. Handle with care during use. Prevent the ceramic handle from impact, compression, dropping, or other external forces.
8. Do not hang heavy items on the ceramic handle or use it beyond its intended design purpose.
9. If minor cracks appear on the ceramic handle, contact customer service for repair.
10. The water efficiency label applied to the spout EX41464T & EX41465T indicate that the water efficiency grade and other performance of the product meet the requirements of GB 25501-2019 "Minimum Allowable Values of Water Efficiency and Water Efficiency Grades for Faucets" which is a marking of product conformity.
11. Use handle EX41445T-PT/SK**/CR**/CN**/RN** and EX41445T-TE** only in combination with spout EX41464T & EX41465T. Refer to spout EX41464T & EX41465T for detailed water efficiency registration information.

10.水嘴EX41464T** & EX41465T**加施的水效标识表明本产品的水效等级等性能符合GB25501-2019《水嘴水效限定值及水效等级》的要求，是产品符合性的一种标识。

11.把手EX41445T-PT**/SK**/CR**/CN**/RN**，EX41445T-TE**分别与出水嘴EX41464T，EX41465T搭配使用，详细水效备案信息见出水嘴EX41464T，EX41465T。

安装尺寸

ROUGH-IN DIMENSIONS

EX41445T-PT**


EX41445T-SK**







EX41445T-CR**

EX41445T-CN**

EX41445T-TE**

EX41445T-RN**

安装步骤	INSTALLATION
	
如图所示，墙面装修好后，拿掉阀芯上的保护套(1)，关闭阀芯。	As figure shown, remove and discard the protectors(1) after completing the finished wall. Turn off the valves.
将齿套(2)安装到阀芯上，用螺钉(3)锁紧。	Install the sleeves(2) onto the valves(1) and secure them with the screws(3).
将连接件(4)旋紧到阀芯上。	Tighten the connectors(4) onto the valves.
将垫片(5、6)装到把手组件(7、8、9、10、11、12)底部凹槽中。	Put the washers(5, 6) into the bottom grooves of the handle kits(7, 8, 9, 10, 11, 12).

	将把手正面的指示标识与把手底座上的红蓝点对齐。 Align the indicators on the handle kits with the corresponding red and blue dots on the handle base.	
分别将带有垫片的把手组件安装到连接件(4)上，在把手底部螺钉孔中装入螺钉(13)并锁紧，使把手组件固定到连接件。	Install the handle kits with washers onto the connectors (4). Insert the screws(13) into the screw holes at the bottom of the handles and tighten to secure the handles to the connectors.	
注意： 把手组件上的指示标识朝上并与把手底座上的红蓝点对齐，如图所示。带有红点的把手组件装在左侧，带有蓝点的把手组件装在右侧。	NOTE: Ensure the indicators on the handle kits face upward and align with the corresponding red and blue dots on the handle base as figure shown. Install the handle with the red dot on the left side and the handle with the blue dot on the right side.	
 EX41445T-PT**	 EX41445T-SK**	 EX41445T-CR**
 EX41445T-CN**	 EX41445T-TE**	 EX41445T-RN**
把手安装完毕处于关闭状态的位置如图所示。		The figures show the correct position of the handles in the closed position.
使用说明		HANDLE OPERATION
对于EX41445T-TE**，顺时针旋转右把手为开，逆时针旋转左把手为开。		For EX41445T-TE**，turn on the left handle counter-clockwise for hot water, turn on the right handle clockwise for cold water.
对于EX41445T-PT**/SK**/CR**/CN**/RN**，逆时针旋转右把手为开，顺时针旋转左把手为开。		For EX41445T-PT**/SK**/CR**/CN**/RN**，turn on the left handle clockwise for hot water, turn on the right handle counter-clockwise for cold water.
清洗说明		CLEANING INSTRUCTIONS
适用于所有加工处理过的表面：以中性肥皂水清洗镀层表面，再以干净的软布彻底擦干整个表面，许多清洁剂，比如氨水、去污粉及洁厕灵等，会对电镀、陶瓷表面造成伤害，切忌使用。		All Finishes: Clean the finish with mild soap and warm water. Wipe entire surface completely dry with clean soft cloth. Many cleaners may contain chemicals, such as ammonia, chlorine, toilet cleaner etc. which could adversely affect the finish, ceramic and are not recommended for cleaning.
有磨损性的清洁用具或清洁剂也不可使用于科勒牌的水龙头及其配件上。		Do not use abrasive cleaners or solvents on Kohler faucets and fittings.